

Quick Start Guide rev.1

How to connect the Wi-Fi to HDMI Pi adapter(s) to TV(s)

The Wi-Fi to HDMI Adapters (Pis) in your scoring rental must be properly connected to the back of the rental TV. An adapter plate will be found inside the scoring rental case.

First, plug the power brick on the plate to the outlet splitter (it comes unplugged to fit inside the case). Next find a Pi adapter box in the case and it to the adapter plate using the Velcro on each surface to secure.

After the TV is properly mounted and secured on the tripod, the Pi adapter plate is mounted to TV on the Velcro strips found in the lower right corner of the TV. Make sure the Pi power switch is off. Next connect the short HDMI cable on the TV to the HDMI port on the Pi. Lastly, plug the TV's power cord into the power outlet splitter.

Use extension cord to connect 120 V AC power to the adapter plate. Using the remote control found inside the top Styrofoam insert of TV box, turn on the TV. Make sure your scoring computer connected to the Wi-Fi Router are both powered up, then turn on the Pi Adapter using the on/off switch on the Pi plate.

You should see the Pi boot sequence appear on the TV screen going to an all-white screen when finished. You are now ready to operate TV displays from scoring system. Recommend opening EliteFLEX MPro application checking <<Status>> under Multiview Monitors. Next under <<Setup>> clear monitors send a message. Call 913.302.4200 if you need support.

